




CAMPINGAZ®

Plancha EX • Plancha EXB

Plancha EX



Plancha EXB














FR Instructions de montage
GB Assembly instructions
DE Montageanleitung
NL Montage-instructies
IT Istruzioni per il montaggio
ES Instrucciones de montaje
PT Instruções de montagem









NO Monteringsinstrukser
DK Monteringsvejledning
SE Monteringsanvisningar
FI Kokoamisohjeet
PL Instrukcja montażu
CZ Návod k montáži příložen
SI Navodila za montažo







SK Návod na montáž
HU Összeszerelési-és használati utasítás
HR Upute za montiranje
RO Instrucțiuni de montaj
BG Указания за монтаж
TR Montaj
GR Οδηγίες συναρμολόγησης



Plancha EX













Plancha EX	Plancha EXB	
1	0	
1	1	
2	2	
2	2	
1	1	
1	1	
1	1	
2	2	
2	2	

Plancha EX	Plancha EXB	
1	1	
1	1	
1	1	
2	2	
1	1	
1	1	
1	1	
Plancha EX	Plancha EXB	
2	2	

Plancha EX	Plancha EXB	F
2	2	
1	1	
1	1	
2	2	
1	1	
1	1	

Plancha EX	Plancha EXB	
1	0	



Plancha EX	Plancha EXB	1:1 B
8	8	
6	6	
10	10	
38	38	
2	2	
1	1	
2	2	
1	1	
2	0	




01



X 8




X 8





02



X 2




X 1






 X 1




03






X 2








04




X 4




05






06




07




F




X1



X1






B







X1


b












08


-  **B**
-  X 1
-  X 1
-  8






B

X 1



10

F




X 1

B

X 1

b



11



X 8

b



X 3

a




X 8




b




X 3

a





OPTION 1





OPTION 2

B

X 4


b




12



 X 6




13



14


Plancha EXB

Plancha EXB







Plancha EX

Plancha EX



15

Plancha EX



Plancha EX

