
EN Key

sw = black

- 1 Control Box
- 2 Monitor
- 3 Adapter cable
- 4 Cinch plug
- 5 Video signal
- 6 Ground
- 7 AMP plug connection

ES Legenda

sw = negro

- 1 Caja de distribución
- 2 Monitor
- 3 Cable adaptador
- 4 Clavija Cinch
- 5 Señal de vídeo
- 6 Masa
- 7 Conector AMP

NL Legenda

sw = zwart

- 1 Schakelbox
- 2 Monitor
- 3 Adapterkabel
- 4 Cinch-stekker
- 5 Videosignaal
- 6 Massa
- 7 AMP-stekkerverbinding

DE Legende

sw = schwarz

- 1 Schaltbox
- 2 Monitor
- 3 Adapterkabel
- 4 Cinch-Stecker
- 5 Video-Signal
- 6 Masse
- 7 AMP-Steckverbinder

PT Legenda

sw = preto

- 1 Caixa de distribuição
- 2 Monitor
- 3 Cabo adaptador
- 4 Ficha Cinch
- 5 Sinal de vídeo
- 6 Terra
- 7 Conetor AMP

DA Forklaring

sw = sort

- 1 Kontrolboks
- 2 Monitor
- 3 Adapterkabel
- 4 Phono-stik
- 5 Videosignal
- 6 Stel
- 7 AMP-stikforbindelse

FR Légende

sw = noir

- 1 Boîte de commande
- 2 Ecran
- 3 Câble adaptateur
- 4 Fiche Cinch
- 5 Signal vidéo
- 6 Masse
- 7 Connecteur enfichable AMP

IT Legenda


sw = nero

- 1 Scatola di comando
- 2 Monitor
- 3 Cavo adattatore
- 4 Spina cinch
- 5 Segnale video
- 6 A massa
- 7 Connettore a spina AMP

SV Teckenförklaring

sw = svart

- 1 Kopplingsbox
- 2 Monitor
- 3 Adapterkabel
- 4 Cinch-kontakt
- 5 Videosignal
- 6 Jord
- 7 AMP-stickkontakt



NO Tegnforklaring

sw = svart

- | | |
|---|----------------------|
| 1 | Koblingsboks |
| 2 | Monitor |
| 3 | Adapterkabel |
| 4 | Cinch-plugg |
| 5 | Videosignal |
| 6 | Jord |
| 7 | AMP-pluggforbindelse |

PL Legenda

sw = czarny

- | | |
|---|----------------------|
| 1 | Skrzynka rozdzielcza |
| 2 | Monitor |
| 3 | Kabel adaptera |
| 4 | Wtyczka Cinch |
| 5 | Sygnal wideo |
| 6 | Masa |
| 7 | Złącze wtykowe AMP |

HU Selitys

sw = fekete

- | | |
|---|--------------------|
| 1 | kapcsolódoboz |
| 2 | Monitor |
| 3 | Adapterkábel |
| 4 | Jack-dugó |
| 5 | Videójel |
| 6 | Földelés (test) |
| 7 | AMP-dugócsatlakozó |

FI Selitys

sw = musta

- | | |
|---|------------------|
| 1 | Kytinrasia |
| 2 | Monitori |
| 3 | Adapterijohto |
| 4 | RCA-pistokkeelle |
| 5 | Videosignaali |
| 6 | Maa |
| 7 | AMP-pistoliitin |

SK Legenda

sw = čierna

- | | |
|---|------------------------------------|
| 1 | Spínací box |
| 2 | Monitor |
| 3 | Adaptérový kábel |
| 4 | Koaxiálny nízkofrekvenčný konektor |
| 5 | Vídeo signál |
| 6 | Ukostonie |
| 7 | Skrutková spojka AMP |

RU Пояснения

sw = черный

- | | |
|---|--------------------------|
| 1 | Разветвительная коробка |
| 2 | Монитор |
| 3 | Переходной кабель |
| 4 | Штекер RCA |
| 5 | Видеосигнал |
| 6 | Корпус |
| 7 | Штекерное соединение AMP |

CS Legenda

sw = černá

- | | |
|---|--------------------------|
| 1 | Spínací box |
| 2 | Monitor |
| 3 | Kabel s adaptérem |
| 4 | Konektor Cinch |
| 5 | Videosignál |
| 6 | Kostra |
| 7 | Propojovací konektor AMP |